

SUN CARE VIVO SPF 10 6797

Formula

Α	 MONTANOV 82 (Cetearyl alcohol/coco-glucoside – SEPPIC) 	3.00 %
	 C12-C15 alkyl benzoate 	20.00 %
	Glycerin	7.00 %
	Tetrasodium EDTA	0.20 %
	 Ethyl hexyl methoxycinnamate 	6.00 %
	 Benzophenone -3 	4.00 %
В	• SEPIGEL 305 (Polyacrylamide/C13.14 Isoparaffin/Laureth-7 - SEPPIC)	1.50 %
	Cyclomethicone	5.00 %
С	Water	QS 100%
D	 SEPICIDE HB (Phenoxyethanol/Methylparaben/Ethylparaben /Propylparaben/Butylparaben - SEPPIC) 	0.30 %
	 SEPICIDE CI (Imidazolidinyl urea - SEPPIC) 	0.20 %
	 DL alpha tocopherol 	0.05 %
	 Fragrance 	0.30 %
	Sodium hydroxyde	
		qs pH7

Procedure

Heat A to 75°C then introduce B , with slowly mixing. Heat C to 75°C. Emulsify A+B in C, start emulsifying for a few minutes with a rotor/stator turbine.

Slowly continue mixing and cooling down. At 40°C, add the components of phase D.

Comments

MONTANOV 82	A glucolipid emulsifier of vegetable origin which is particularly convenient for formulas with activs and for the emulsifying of the sunfilters. Gives emulsions a soft texture and acts as a moisturizing vector.
SEPIGEL 305	A thickening and emulsifying agent, easy to use and ideal for fluid emulsions
SEPICIDE HB / CI	Preservative.
Characteristics	

Appearance	White fluid cream.
рН	about 7
Viscosity	about 28,000 mPa.s BROOKFIELD LV4 6rpm.
Stability	Stable at RT/40°C and after freeze-thaw cycles -5 / +40



Evaluation

SPF - in vitro stable over time (after 1month/3 monthes /6 monthes /1 year):13 \pm 2/13 \pm 2/15 \pm 1/15 \pm 1 (SEPPIC method 57CO033 : support Vitroskin® , spectrophotometer LABSPHERE®)

SPF - in vivo (at 1 month) : 12 \pm 2 (5 volunteers – report IEC 00164RD)

Notes

Cyclomethicone: DC345 (DOW CORNING) Fragrance : APHRODIS X010.029 (QUEST) Ethyl hexyl methoxycinnamate: octinoxate UVINUL MC80 (BASF) Benzophenone-3: oxybenzone UVINUL M40 (BASF)

6797 - SEPPIC - A0207

Since this formula has not undergone toxicological analysis, the proposed use and handling of the products is for reference purposes only and SEPPIC accepts no liability for their use by any party.

 SEPPIC SA
 SEPPIC UK Ltd
 SEPPIC Inc
 SEPPI

 33(0) 1 40 62 55 55
 (44) 208 577 8800
 (1) 973 882 5597
 (39) 0

SEPPIC Italia (39) 02 38009110

SEPPIC Shangai (86-21) 64 43 78 15